Module 1: SCALES

Objectives

- Learning the use of set squares/ drafter for technical drawing.
- Basic drawing skills.
- Use of scales in engineering drawing.
- Construct plain scale and Vernier scale as per requirement.

Necessity

- Drawings drawn with the same size as the objects are called full sized drawing.
- It is not convenient, always, to draw drawings of the object to its actual size. e.g. Buildings, Heavy machines, Bridges, Watches, Electronic devices etc.
- Hence scales are used to prepare drawing at
 - Full size
 - Reduced size
 - Enlarged size

Types of Scale

Engineers Scale :

The relation between the dimension on the drawing and the actual dimension of the object is mentioned numerically (like 10 mm = 15 m).

Graphical Scale:

Scale is drawn on the drawing itself. This takes care of the shrinkage of the engineer's scale when the drawing becomes old.

Representative fraction (R.F.)

When a 1 cm long line in a drawing represents 1 meter length of the object,


$$R.F = \frac{1cm}{1m} = \frac{1cm}{1 \times 100 \, cm} = \frac{1}{100}$$

Types of Graphical Scale

- Plain Scale
- Diagonal Scale
- Vernier Scale
- Comparative scale

Plain scale

Problem 4-1. (fig. 4-1): Construct a scale of 1:4 to show centimetres and long enough to measure upto 5 decimetres.



- (i) Determine R.F. of the scale. Here it is $\frac{1}{4}$.
- (ii) Determine length of the scale. Length of the scale = R.F. \times maximum length = $\frac{1}{4} \times 5$ dm = 12.5 cm.
- (iii) Draw a line 12.5 cm long and divide it into 5 equal divisions, each representing 1 dm.
- (iv) Mark 0 at the end of the first division and 1, 2, 3 and 4 at the end of each subsequent division to its right.
- (v) Divide the first division into 10 equal sub-divisions, each representing 1 cm.
- (vi) Mark cms to the left of 0 as shown in the figure.

To distinguish the divisions clearly, show the scale as a rectangle of small width (about 3 mm) instead of only a line. Draw the division-lines showing decimetres throughout the width of the scale. Draw the lines for the sub-divisions slightly shorter as shown. Draw thick and dark horizontal lines in the middle of all alternate divisions and sub-divisions. This helps in taking measurements. Below the scale, print DECIMETRES on the right-hand side, CENTIMETRES on the left-hand side, and the R.F. in the middle.

To set-off any distance, say 3.7 dm, place one leg of the divider on 3 dm mark and the other on 7 cm mark. The distance between the ends of the two legs will represent 3.7 dm.

https://www.youtube.com/watch?v=_t_Zhuibno0

Vernier scale

- A Vernier scale consists of (i) a primary scale and (ii) a vernier.
- The primary scale is a plain scale fully divided in to minor divisions.
- The graduations on the vernier are derived from those on the primary scale.

Least count (LC) is the minimum distance that can be measured.

Forward Vernier Scale:


MSD>VSD; LC = MSD-VSD

Backward Vernier scale:

VSD>MSD; LC = VSD - MSD


Vernier scale

- Length A0 represents 10 cm and is divided in to 10 equal parts each representing 1 cm.
- B0 = 11 (i.e. 10+1) such equal parts = 11 cm.
- Divide B0 into 10 equal divisions. Each division of B0 will be equal to 11/10 = 1.1 cm or 11 mm.
- Difference between 1 part of $A\theta$ and one part of $B\theta = 1.1$ cm -1.0 cm = 0.1cm or 1 mm.



Vernier scale

Question: Draw a Vernier scale of R.F. = 1/25 to read up to 4 meters. On it show lengths 2.39 m and 0.91 m



- Length of Scale = $(1/25) \times (4 \times 100) = 16$ cm
- Draw a 16 cm long line and divide it into 4 equal parts. Each part is 1 meter. Divide each of these parts in to 10 equal parts to show decimeter (10 cm).
- Take 11 parts of dm length and divide it in to 10 equal parts. Each of these parts will show a length of 1.1 dm or 11 cm.
- To measure 2.39 m, place one leg of the divider at A on 99 cm mark and other leg at B on 1.4 mark. (0.99 + 1.4 = 2.39).
- To measure 0.91 m, place the divider at C and D (0.8 +0.11 = 0.91).

Assignment#1

Construct a Vernier scale of meters to read up to centimeters when 8 cm represents 1 m. State R.F. and measure distance of 1.89 cm with the help of the scale. The scale should be long enough to measure 2 m


Help:

https://www.youtube.com/watch?v=ajzIINxL0z0&t=1311s

Last date of submission: 6 Jan 2022

Instruction regarding format of assignments

- Assignment no., name, roll no. should be clearly written at the top of every A4 sheet.
- Assignments are to be submitted in a single pdf file of image(s) of the hand drawn A4 sheet(s) in MS TEAMS. The file name should be in following format.



December 28, 2021 XES 51: Engineering Graphics 12